



X-431 IMMO PLUS-Programmable Module Installation(PMI) Function

How to clear Initial Configuration Not Completed of ABS after replacing a new or secondhand programmed ABS module for Ford F-Series Super Duty 2020 in around 2 mins?

1. Tap IMMO function on the screen of X-431 IMMO PLUS after connecting the DLC socket with the DBSCarVII VCI




2. Choose FORD IMMO software




X-431 IMMO PLUS-Programmable Module Installation(PMI) Function

3. Make sure the software is updated to the latest version and Choose OK




4. Choose “Anti-Theft System Detection”




X-431 IMMO PLUS-Programmable Module Installation(PMI) Function

5. Choose “Automatically Search”




6. Switch on the ignition according to the notification then choose “OK”






X-431 IMMO PLUS-Programmable Module Installation(PMI) Function



7. choose “Immobilizer System Selection” to see the car’s available systems





8. Choose the relative “ABS”




X-431 IMMO PLUS-Programmable Module Installation(PMI) Function**9. Choose “Read Fault Code” to check the current status of the car****10. Choose “KOEO” to run the detection**

X-431 IMMO PLUS-Programmable Module Installation(PMI) Function**11. Check the Fault Code - Initial Configuration Not Completed, Tap “return”****12. Tap “return” again**


X-431 IMMO PLUS-Programmable Module Installation(PMI) Function**13. Choose “Special Functions” within the ABS menu****14. Choose “PMI” according to the Fault Code**

X-431 IMMO PLUS-Programmable Module Installation(PMI) Function

15. Read function introduction, Choose “YES”




16. Read and prepare for the preconditions then Choose “YES”




X-431 IMMO PLUS-Programmable Module Installation(PMI) Function

17. Choose “NO” since we replace the original module with a secondhand or a new module




18. Double check the ignition status then Choose “OK”




X-431 IMMO PLUS-Programmable Module Installation(PMI) Function

19.The X-431 IMMO PLUS is functioning



20.Switch the key to position 0 then choose “OK”



X-431 IMMO PLUS-Programmable Module Installation(PMI) Function

21.The module is properly adjusted and the Fault Code is cleared right away

